## TYPICAL WIRING DIAGRAM SPLIT PHASE 120/230VAC (L1, L2, N, GROUND)

For questions, comments or concerns please call 206-285-2990 or email at info@smartplug.com

## tions in Power Delivery THIS WIRING DIAGRAM IS FOR SPLIT PHASE SYSTEMS THAT DO NOT HAVE A TRANSFORMER



